



BERTH SOUNDINGS

TIM R. GLASHEEN, P. ENG.
DIRECTOR OF ENGINEERING AND MAINTENANCE

CAPT. G. J. HOUSTON
PRESIDENT AND C.E.O.

GRAHAM KEE
DIRECTOR OF MARINE OPERATIONS AND SECURITY
OFFICE: (604)665-9095

INDEX TO DRAWINGS AND GENERAL NOTES

SHEET 1	INDEX TO DRAWINGS AND GENERAL NOTES	SHEET 14	ROGERS SUGAR	SHEET 27	LYNNTERM EAST GATE - WEST
SHEET 2	LOCATION MAP - ENGLISH BAY TO SECOND NARROWS	SHEET 15	AGRICORE UNITED (U.G.G.)	SHEET 28	LYNNTERM WEST GATE
SHEET 3	LOCATION MAP - SECOND NARROWS TO PORT MOODY	SHEET 16	VANTERM	SHEET 29	NEPTUNE TERMINALS LTD.
SHEET 4	LIONS GATE BRIDGE - CLEARANCES	SHEET 17	AGRICORE UNITED (PACIFIC ELEVATORS)	SHEET 30	SASKATCHEWAN WHEAT POOL
SHEET 5	IRONWORKERS MEMORIAL SECOND NARROWS BRIDGE - CLEARANCES	SHEET 18	CASCADIA TERMINAL	SHEET 31	JAMES RICHARDSON INTERNATIONAL
SHEET 6	SECOND NARROWS RAIL BRIDGE - CLEARANCES	SHEET 19	CHEVRON CANADA LTD.	SHEET 32	PIER 94
SHEET 7	SECOND NARROWS POWERLINE - CLEARANCES	SHEET 20	SHELL CANADA LTD.	SHEET 33	FIBRECO EXPORT INC.
SHEET 8	BURNABY - BELCARRA POWERLINE - CLEARANCES	SHEET 21	KINDER MORGAN CANADA INC. (TERASEN)	SHEET 34	VANCOUVER WHARVES - EAST
SHEET 9	BURNABY - IOCO POWERLINE - CLEARANCES	SHEET 22	PETRO CANADA LTD.	SHEET 35	VANCOUVER WHARVES - WEST
SHEET 10	CANADA PLACE	SHEET 23	PACIFIC COAST TERMINALS	SHEET 36	DELTAPORT - BERTH 1
SHEET 11	MAIN STREET DOCK	SHEET 24	IMPERIAL OIL LTD.	SHEET 37	DELTAPORT - BERTH 2
SHEET 12	CENTERM - WEST	SHEET 25	CANEXUS CHEMICALS	SHEET 38	WESTSHORE TERMINALS - BERTH 1
SHEET 13	CENTERM - EAST / BALLANTYNE PIER	SHEET 26	LYNNTERM EAST GATE - EAST (INCL. DOW)	SHEET 39	WESTSHORE TERMINALS - BERTH 2

GENERAL NOTES :

1. PIERS ARE SHOWN WEST TO EAST ON THE SOUTH SHORE AND EAST TO WEST ON THE NORTH SHORE.
2. BRIDGES AND CROSSINGS ARE SHOWN BEGINNING AT THE ENTRANCE TO BURRARD INLET.
3. FACILITIES AT ROBERTS BANK ARE SHOWN AT THE END OF THE BOOK.
4. ALL SOUNDINGS WERE MADE AT THE DATES SHOWN ON EACH SHEET, AND ARE VALID ONLY ON THAT DATE.
5. ALL SOUNDINGS ARE IN METRES AND DECIMETRES BELOW ZERO TIDE.
6. DOCK ELEVATIONS ARE SHOWN IN METRES ABOVE ZERO TIDE.

CLICK TERMINAL NAME TO VIEW INDIVIDUAL SOUNDINGS CHART